



英诺激光
INNO LASER



Advanced
Optowave

This instruction is applicable to nanosecond models such as FIT, FOTIA, and FORMULA. The software operation methods and interface definitions are all the same.

Refer to the corresponding chapters for specific requirements of electrical and water cooling machines.

INNO LASER TECHNOLOGY CORPORATION LIMITED

All rights reserved.

V1.2



Table of Contents

1	Laser safety instructions	4
1.1	Laser safety Level	4
1.2	Laser Safety Responsibilities	4
1.3	Laser Safety Operation Guide	4
1.4	Warning and Safety Signs	5
1.5	Laser Safety Characteristics	6
1.6	Laser Safety Commitment	6
2	Laser Interface Description And Packing List.....	7
2.1	Interlock Pins	7
2.2	Packing list.....	7
3	Laser System Environmental Requirements.....	8
3.1	Electrical Requirements	8
3.2	Environmental Requirements.....	8
3.3	Chiller Requirements (Only for water-cooled lasers)	8
3.4	Operating Precautions	9
4	AOC NANO Laser Controller Software.....	10
4.1	Software List and System Requirements	10
4.2	Installation and Operating Problem Solutions	10
5	New Graphical User Interface --- GUI	11
5.1	Operator Page Introduction	11
5.2	Engineer Page Introduction.....	12
5.3	The Working Modes of The Laser	14
6	Laser Basic Operations.....	15
6.1	Laser Start-up Procedure.....	15
6.2	Laser Shutdown Procedure	16
6.3	Enable The Automatic Start-up Function of The Laser	17
6.4	Laser spot replacement operation method	18
6.5	Laser power self-optimization	18
7	Laser Triggering Methods	20
7.1	Introduction.....	20
7.2	The Connection of The Laser and The Marking Card	21
8	Maintenance.....	23



8.1	Maintenance Schedule	23
8.2	Special Response from Laser	25
8.3	Laser alarm promotion and solutions	26
8.4	Laser common malfunction troubleshooting	27



1 Laser safety instructions

1.1 Laser safety Level

The laser is a Class IV High Power Laser. Extreme care should be taken when operating. The laser beam is a fire and safety hazard. Only personnel who are trained with the safety precautions listed in this manual should be allowed to operate the laser system. Precautions must be taken to prevent accidental exposures to direct or reflected laser beam. Both diffuse and specula reflections can cause severe skin or eye damages. Proper eye protection must be worn at all times. Direct eye contact with the output beam from the laser will cause serious damage and even blindness.

1.2 Laser Safety Responsibilities

Lasers are engineered industrially and undergo rigorous tests to ensure that they are safe and reliable under reasonable using conditions. If operators do not operate in accordance with the correct safety guidelines, it will be extremely dangerous to both their body and property. Especially when the output wavelength of the laser is in an invisible range, the danger also increases accordingly. If operators do not use the lasers in accordance with the normal use guidelines of our company, our company will not bear any legal liability for all personal injuries resulting therefrom.

1.3 Laser Safety Operation Guide

Danger!

Before using the laser, operators must read this manual and strictly follow the operating procedures in this user manual. Precautions must be taken to prevent accidental injuries caused by direct or reflected light beams. Non-operators must be evacuated outside the laser radiation hazard area.

The greatest danger is the direct exposure to the main laser beam when using a laser. In addition to the main beam, a few smaller weaker power beams may exit at different angles near the laser system. The weaker beams may still be sufficiently intense to cause eye damage.

Laser light is powerful enough to burn skin, clothing or paint. They can ignite volatile substances such as solvents even at some distance. The laser beam can damage light sensors in video cameras and photo diodes. The user is advised to follow the precautions below and in this manual.

- Only qualified users who are familiar with standard laser safety practices and who are aware of the dangers involved should be allowed to have the access the laser.
- Don't look at the output beam directly. Specula and diffuse reflections are hazardous.
- Avoid wearing jewelry or any reflective items when operating the laser.
- Use protective eye wear that is right for the laser wavelength, that is, always use optical protective goggles during laser operations. Consult your organization's Laser Safety Officer in accordance with your laser safety procedures.
- Use a suitable wavelength fluorescence card to verify that the laser beam is off for safety.
- Be sure to use non-reflective beam stops to block the laser beam.



- Set up the laser beam so that it is not at eye level, the beam should be above or below eye level both at a seated position and a standing position.
- Post highly visible warning-signs near the laser operation area for Class IV laser products.
- Set up a dangerous zone around the laser, use safety interlocks to prevent non-experienced personnel from entering into the working area.
- Laser light is very bright and intense compared with conventional light sources. It poses a significant safety hazard. All laser users, and everyone near the laser system, should be aware of the dangers of using a class IV laser such as the laser system.
- Observe and follow all safety precautions in this manual.
- Extreme cautions should be taken when using volatile substances in the laser area.
- Never direct exposure to the laser beam. The intensity of the beam can easily cause flesh burns or ignite clothing.

Danger ! Visible light, invisible light, and ultraviolet radiation.

Laser produces both visible and invisible radiation. The invisible radiation has a wavelength of 1064nm which corresponds to the infrared (IR) optical region and 355-351nm which corresponds to the Ultra Violet (UV) optical region. The visible radiation is 532-527nm which corresponds to the Green (GR) optical region. All these radiations can easily cause permanent damage to the retina.

1.4 Warning and Safety Signs

LASER RADIATION WARNING LABEL		ENERGY & WAVELENGTH LABEL (Sample)	
APERTURE LABEL		CLASS 4 LASER PRODUCT LABEL	
MANUFACTURING IDENTIFICATION LABEL (Sample)	Model No. FOTIA(ONE)-355-5-30-A Serial No. A174200094 Manufactured 2024/xx/xx Power Rating DC12V 120W THIS EQUIPMENT CONFORMS TO PROVISIONS OF US 21 CFR 1040.10&1040.11-US PATENTS PENDING MADE IN CHINA 305124		



1.5 Laser Safety Characteristics

- External Interlock Connector: A detachable interlock connector is provided at the back of the laser control unit, which has two pins inside that can be connected to an external interlock switch. When the two pins are disconnected, the laser will stop working, displaying an alarm for the disconnection of the external interlock device. At the same time, the buzzer will sound an alarm sound. When the fault is resolved (such as the interlock switch being reconnected), clearing the fault alarm or power off and restarting the laser will restore normal operation.
- Key switch control: The laser cannot be turned on when the key is turned off.
- Laser emission warning light: The on and off of the LED light on the laser can also indicate whether the laser is on or off. However, users cannot rely solely on this function to determine whether the laser is on or off. When using the laser, you need to be very careful at all times.

1.6 Laser Safety Commitment

The laser itself is safe, but protection must be taken when using it. Both equipment manufacturers and end users should abide by the safety requirements of lasers. This is the basis for ensuring safe production. They should commit to installing laser protection devices that can isolate, block, and protect in the use scenario, even when the laser is not turned off. Laser safety requirements are included in IEC 60825-1:2014& CAN/CSA-E60825-1:15, GB 7247.1-2012.



2 Laser Interface Description And Packing List

2.1 Interlock Pins

Pins	Signal Function	Comment
1	GATE	Internal trigger (5V TTL level trigger)
2	Trigger	External trigger (PWM signal trigger)
3	FPS	
4	Interlock	Interlock, short with any GNDiso
5	EMS INPUT	
6	GNDiso	
7	ALARM OUT	Alarm output, 5V output
8	SYNC OUT	
9	GNDiso	
10	GNDiso	
11	GNDiso	
12	START INPUT	Key switch, short with any GNDiso
13	RS232 TXO	RS232 Signal Transmitter
14	RS232 RXO	RS232 Signal Receiver
15	Laser Ready	Laser self-start completion signal (5v)

2.2 Packing list

Physical Objects	
Interlock Connector	1
Power Cord	1
Waterpipe	The water-cooled model will have two water pipes.
Laser Test Report	1

Caution:

When installing the water pipe, it is necessary to press it inward with force to prevent water leakage. The length of the water pipe connection is about 22mm.



3 Laser System Environmental Requirements

3.1 Electrical Requirements

Parameter	Requirements			
laser type	FIT 3W/5W FOTIA-AIR	FIT 10W FOTIA-WATER FOTIA(PRO) FORMULA(S)	FORMULA(ULTRA) 30W FORMULA DiamondCut	FORMULA(ULTRA) 40/50/60/80W
power supply voltage	DC-12V	DC-24V	DC-24V	DC-24V
Suggested power supply	350W	450W	600W	1000W

3.2 Environmental Requirements

Parameter	Requirements
Ambient Operating Temperature	5°C to 40°C
Relative Humidity	5% to 90%(non-condensing)
Vibration	Keep away from Vibrations
Altitude	Sea level to 3000m

Caution:

The FOTIA air-cooled model requires higher power stability. Its ambient temperature is 15°C - 35°C.

3.3 Chiller Requirements (Only for water-cooled lasers)

Parameter	Requirements		
laser type	≤10W	15W-20W UV 15W-35W GR	≥30W UV ≥60W GR
Cooling Capacity	300W	500W	1000W
Water Flow	3L -5L/min		
Pump Height	10m-20m		
Temperature Accuracy	±0.1°C		



3.4 Operating Precautions

- The laser controller power line has three reserved connectors: +V, GND, and PE. Please correctly connect them to a switching power supply that meets the power requirements.
- The laser needs to be installed horizontally on the platform. If you need to install it in other directions, please consult Inno technical support personnel.
- The laser should be equipped with a chiller that meets the requirements. Excessive water pressure will squeeze the cavity and cause power attenuation.
- The water coolant should be replaced at least once every two months. It is recommended to use automotive antifreeze to prevent water blockage and extend the water replacement cycle.
- Install the chiller in a convenient and well-ventilated spot. The chiller will draw cool air in from the front of the unit and will exhaust warm air through the rear of the unit. Caution should be taken to ensure that the chiller can draw and expel air freely and that it will not recirculate its exhaust warm air as this will prevent the chiller from maintaining a stable water temperature.
- The optical path behind the laser window mirror needs to be sealed. It is recommended to use a beam expander directly installed on the window mirror, which can effectively extend the service life of the window mirror.

Note: The window mirror is a consumable and is not covered by the warranty.



4 AOC NANO Laser Controller Software

4.1 Software List and System Requirements

The laser control software does not need to be installed. It can be downloaded directly from our official website or official account. Double click to open it.

- Software Name: NANO GUI
- Please install Microsoft .NET Framework 4.5.1 or a higher version software on the computer to support software operation.

4.2 Installation and Operating Problem Solutions

- Please use RS232 direct connection (2, 3, 5-pin direct connection), or use a USB to serial communication cable. If you choose a serial to USB data cable as the RS232 communication cable, please install the corresponding driver. Some systems may require a PC restart after installation.
- If the software is unable to start or error, please confirm whether the installation software version and the Microsoft .net framework software is correct. If there are multiple .net framework software versions, please unload them all and reinstall one.
- When unable to find the serial port, please check if the serial port driver has been installed. You can open the device manager to check if the com port is not enabled.
- The software running interface displays "Searching for laser.....Please make sure the port connection is good", which means the com port is wrong, please change to the correct com port.
- The software running interface displays "Error! Unable to switch to remote state", please check if there is any alarm sound in the communication cable and laser. If there is an alarm, please first troubleshoot the laser problem and then restart the laser controller.



5 New Graphical User Interface --- GUI

5.1 Operator Page Introduction



Figure 1: Operator Screen

Connect the computer and the laser with the serial communication cable, launch the GUI on your computer.

The connectable serial port might not be displayed in the “Serial Port” drop down menu. Please click "Search" button. Then, the system will automatically search and display the connectable serial port. Then click "connect", the system will be automatically connected and enter the initialization stage.

(Note: It is necessary to select the correct serial port by yourself if multiple serials are connected in the computer, otherwise the system will display an error message. Please select the port again.)

● Laser Status Section

Laser Status displays the operating status of the laser system. After the laser is initialized normally, the status bar will display various parameters, especially the power factor and working mode code.

● Temperature Section

Environment: The ambient temperature at the installation location of the laser.

Laser Head: The shell temperature of the laser resonator.

Diodes: The current temperature of the laser diode.

Crystal 1: The actual temperature and the set temperature of the SHG crystal.

Crystal 2: The actual temperature and the set temperature of the THG crystal.

● Parameter Setting Section

PRF: Sets the working frequency of the laser.

D1 current: Sets the current of pump diode 1 (Note: Refer to the factory test report).

D2 current: Sets the current of pump diode 2 (Note: Refer to the factory test report, do not set any value if there is no such parameter).



Power Factor: Sets the laser output power value (PWF function, 50 - 950 adjustable, the higher the value, the higher the output power).

- Laser Operation Section

SHT: Turns on or off the laser shutter.

DIO: Turns on or off the laser pump diode.

QSW: Turns on or off the laser Q-switch.

- Other

Reset: The button to eliminate alarms. The alarm can be eliminated by pressing this button when the malfunction is resolved.

Report (Create): The button for generating the report for the internal laser parameters. When the laser system fails, the user can create a report and send it to the INNO's engineer for quick analysis and solution for the problem.

(Note: By default setting, the laser works in "13" external control mode. If the interface shows that the laser works in "01" internal control mode, the laser outputs at low level, so please set up a power meter or shielding device for protection.)

5.2 Engineer Page Introduction

Click the "Engineer" and enter the password "AOC" (in capital letters), shown in Figure 2 and 3.




Figure 2: Password AOC




Figure 3: Engineer screen

Parameter setting section/Laser operation section/Temperature section are the same as the functions of the operator screen.

- Opera Level Section

Gate: Switch between high-level triggering and low-level triggering.

PWM: Switch between rising-edge triggering and falling-edge triggering.

- FPS Mode Section

This section is used to switch the laser control mode.

- Command Box Section

The window is used to input serial port communication instructions.



5.3 The Working Modes of The Laser

There are two commonly used modes for the lasers, namely Mode 01 and Mode 13, as shown in Figure 4.

For Mode 01, please connect "Gate In" with high and low level TTL signal.

For Mode 13, please connect "Trig in" with a PWM signal.

Turn off "QSW" before changing the laser working mode, then select the desired laser working mode from the drop-down menu and click the "Change" button. Please don't open the "QSW" until "Present Mode" displays the selected mode.

(Note: For the customer's request for high-level output, it can be switched through the command: GTR=0/1 to change the high and low-level control output. By default, the laser system is set to low-level output)




Figure 4: Laser working mode



6 Laser Basic Operations

6.1 Laser Start-up Procedure

- Connect the laser to the computer with RS232, turn on the laser power, and turn on the laser key switch. Warm up the machine for 5-8 minutes, or until the cooling system reaches the set temperature value and stabilizes if there is chiller.
- Launch the AOC GUI on your computer. Click “Search” button, select the serial port you are using. On the GUI click “Connect” button to connect the computer to the laser controller. The status showing in the system.




Figure 5: Laser initializing

- After 2 minutes, the following interface appears, indicating that the software has been correctly connected.
- Open in sequence “SHT-ON” “DIO-ON” (When turning on the pump source, wait for the current to rise until the system status bar displays the correct current value), finally turn on “QSW-ON”.




Figure 6: Laser startup completed interface

- Wait for 3-5 minutes for the machine to warm up, then you can adjust the optical path and set the power meter based on the CW light at this time.

Note: It is important that the system is allowed to thermally stabilize for 20 minutes when power is first applied to the system. The system will maintain a stable harmonic temperature.

6.2 Laser Shutdown Procedure

- Turn off the “QSW”, turn off the “DIO” (wait for the current to reach 0A), and finally turn off the “SHT”.
- Click “Disconnect” button, disconnect from the laser.
- Turn off the power.

Note: After shutting down the laser system, it is recommended to keep the main power switch of the controller turned on to ensure the power supply of the controller, because the crystal temperature control module of the laser controller is still in working condition at this time, which can reduce the warm-up time when the laser system is restarted and extend the working lifetime of the crystal.



6.3 Enable The Automatic Start-up Function of The Laser

Note: To determine whether the laser version supports one-key startup, please contact our engineer to confirm before setting it up yourself. Laser power less than 10W can use this function.

- Click the “Engineer” and enter the password “AOC” (in capital letters).



Figure 7

- Selecting “ADC Switch: on”, click the “Change” button. the automatic start-up setting is completed.




Figure 8

After the automatic startup setting is completed, when the laser is powered on next time, it will automatically complete the startup steps without opening the laser control software again.

If you want to turn off the automatic startup program, select “ADC Switch: off”.

Note: The entire startup process lasts about 1.5 minutes. Please do not perform other operations before seeing the laser indicator light to complete the startup, to avoid laser shutdown.



6.4 Laser spot replacement operation method

This step is only applicable to models with a dot changing mechanism: FOTIA(i), FOTIA(pro), FORMULA(i), FORMULA(ultra).

Note: During the process of changing points, the Q drive needs to be kept in a closed state. The point cannot be changed when the Q drive is in an open state.

- After the laser software is connected to the laser, enter the “engineering” interface. Click “Get Pos” in the “Change point” area on the right side of the interface to obtain the point currently used by the laser.




Figure 9

- There are a total of 5 points available for the laser. Before changing points, it is necessary to first turn off the “QSW”. Then, select other points through the drop-down menu and click “Change point” to perform the point change operation. After the point change is completed, the system will prompt.

6.5 Laser power self-optimization

This step is only applicable to models with power self-optimization: FOTIA(pro), FORMULA(ultra).

Note: During automatic optimization, the laser will continuously output strong light. Please be sure to take precautions. Use light-absorbing materials to block the optical path to avoid damage.

- After the laser software is connected to the laser, enter the “engineering” interface, click “QSW-off”, “DIO-off”, and “SHT-off” in turn, and then perform the next operation in the “automatic optimization” area on the right side of the interface.




Figure 10

- Click “Start opt”. The system will pop up a safety prompt. After clicking the “OK” button, the laser will start automatic optimization. At this time, the optimization progress bar will be displayed. After the progress bar is completed, the software will prompt “Automatic optimization completed”.





Figure 11




7 Laser Triggering Methods

7.1 Introduction




- Gate In:

Provides the user with another option to control the lasers ON/OFF function for their application. During the low portion of a TTL signal (0~0.4V) the laser will be enabled (laser on). During the high portion of the signal (3.7~5V) the laser will be disabled (laser off).



- Trigger In:

Provides the user to control the laser frequency as desired. The input signal must be +5V TTL, with a negative pulse width of no less than 1us.





7.2 The Connection of The Laser and The Marking Card

● EzCad

Gate In:

EzCad CON2(DB25)	Interlock Pins
PIN 12 (LASER-)	PIN1 (GATE)
PIN 3/6/7/8/10/11/19 (GND)	PIN 6/9/10/11 (GNDiso)

Trigger In:

EzCad CON2(DB25)	Interlock Pins
PIN 22 (PWMTTL)	PIN2 (TRIGGER)
PIN 3/6/7/8/10/11/19 (GND)	PIN 6/9/10/11 (GNDiso)

Note: The signal line must be a coaxial cable with shielding.

● MarkingMate PMC2

Gate In:

Markingmate P2 (DB15)	Interlock Pins
PIN 6 (LO_Laser On/Off)	PIN1 (GATE)
PIN 3/15 (GND)	PIN 6/9/10/11 (GNDiso)

Trigger In:

Markingmate P2 (DB15)	Interlock Pins
PIN 4 (Laser1_PWM)	PIN2 (TRIGGER)
PIN 3/15 (GND)	PIN 6/9/10/11 (GNDiso)

Note: The signal line must be a coaxial cable with shielding.



- RTC4

Gate In:

RTC4 (DB9)	Interlock Pins
PIN 2 (LASER ON)	PIN1 (GATE)
PIN 6/7 (GND2)	PIN 6/9/10/11 (GNDiso)

Trigger In:

RTC4 (DB9)	Interlock Pins
PIN 1 (LASER1)	PIN2 (TRIGGER)
PIN 6/7 (GND2)	PIN 6/9/10/11 (GNDiso)

Note: The signal line must be a coaxial cable with shielding.

- SAMLIGHT

Gate In:

SAMLIGHT (DB37)	Interlock Pins
PIN 31 (LASER_GATE)	PIN1 (GATE)
PIN 14/15/24 (GND)	PIN 6/9/10/11 (GNDiso)

Trigger In:

SAMLIGHT (DB37)	Interlock Pins
PIN 13 (Laser_A)	PIN2 (TRIGGER)
PIN 14/15/24 (GND)	PIN 6/9/10/11 (GNDiso)

Note: The signal line must be a coaxial cable with shielding.



8 Maintenance

8.1 Maintenance Schedule

Frequency	Detail
Monthly	Check and optimize the maximum power of the laser
Every 2 Months	Check the laser output window for damage
Every 3 Months	Check the chiller coolant level (if applicable)
Every 6 Months	Replace the chiller coolant
Every 12 Months	Clean the chiller and the controller's fans of dust

- Optimize the maximum power of the laser

Regular measurement and optimization of laser power can improve the stability and reliability of product usage, and it is also beneficial to the lifespan of the laser.

The UV laser is equipped with two (2) harmonic crystals. GR laser only has crystal 1. Below are the steps to optimizing Crystal 2's temperature. The same steps are also applicable to optimizing crystal 1.

- ✧ While in Operator GUI please hit the Engineer Tab and then the password AOC when prompted. Once the Engineer GUI is opened located the Crystal 2 Temperature Adjustment Section, see figure 9.



Figure 9

- ✧ During this procedure, please make sure that there is a power meter in front of the laser and that you are monitoring the power as you make the following adjustments.
- ✧ Using the “UP” arrow located to the right of the set temperature make small 0.5°C (this can be done by checking the 0.1 box) changed to the set temperature. It will take a few seconds for the crystal to respond to the change.
- ✧ If the power on the power meter showed an increase in power, continue to make 0.5°C adjustments until you see the output power decrease, at this point you have past the



optimal crystal temperature.

- ✧ Once the maxima temperature has passed, please start lowering the set temperature in 0.2°C steps, until the laser has reached its peak performance.

Once the fine tuning is completed, please click the Operator Tab and return to Operator GUI.

- Check the laser output window for damage

It is recommended that the laser output window be checked for damage approximately every 2 months. This can be done by looking at the area around the main output beam. An excessive amount of beam scatter may be the result of a damaged output window. One side of the laser window is exposed to the environment so it can be damaged if dust or contamination settles on the surface. If an excessive amount of scatter is found the laser window can be replaced by removing the screws that hold it in place, pull out the window, insert a new window and secure using the original screws. Please note the orientation of the Brewster window and make sure that the replacement window is installed in the same orientation.

- Check the chiller coolant level (if applicable)

Some laser models require the use of an external chiller unit. This chiller unit provides chiller liquid coolant to the laser head and the controller to regulate their temperatures to a set level. The coolant level of the chiller unit should be checked every 3 months to ensure that it is at its maximum capacity.

- Replace the chiller coolant

The regular coolant replacement ensures that the system is free of contamination and that the coolants anti corrosive properties are not depleted. To drain the system the chiller must be in the OFF position and the AC cord unplugged. Remove the VENT plug and remove the rubber fill plug. Locate the female water connector that is next to the coolant. Remove one of the water hoses from the system. Insert one end into the plug labeled DRAIN. Press in the male connector of the other end of the water hose and coolant should flow out. The reason why you must press the tip of the male water connector is because the water fittings are self-sealing, and they are designed to prevent unwanted coolant leakages. Pressing the tip of the fitting will open the seal and allow coolant to flow. When the coolant stops flowing disconnect the water hoses from the DRAIN fitting and fill the clear plastic tube with fresh coolant so that it reached the MAX fill line. Turn on the system and allow the coolant to circulate. The coolant level will drop as the coolant fills the cavity of the laser and the coolant lines. Add coolant as necessary.

- Clean the chiller and the laser's fans of dust

During the long-term use of the cooling fan of the laser, dust will accumulate on it, resulting in a decline in heat dissipation performance. Compressed gas can be used to clean the fan and the heat sink. Pay attention to protecting the window mirror and other lenses during the cleaning process.



8.2 Special Response from Laser

Special case	Response from laser is always 6 digits (each digit is between 0-9)	Comments
Any error message: wrong message, wrong message ending (0xD, 0xA), or incorrect value range.	ERROR	Need to check the message, the ending and value. If it is caused by RS232 bit error rate, PC needs to resend message
PC tries to send message to laser driver when it is busy with other high priority task.	BUSY	Wait for laser driver to finish its task
When laser alarms any command sent to laser driver will be ignored and get a return of "ALARM", followed by the alarm condition code.	Example: ALARM 000007	Indicates laser is alarming because of interlock open
When alarm condition cleared, laser will require user to press RESET button by GUI. Before the button is pressed any commands to laser will be ignored and get a return "RESET"	RESET	RESET by user required



8.3 Laser alarm promotion and solutions

Code	Malfunction Description	Solutions	
000001	Diode Temperature High	Air cooling: Check whether Diode heat sink is blocked; Check whether the fan and TEC plate works.	Water cooling: Check whether the chiller works whether the water temperature and pressure is normal ; whether the water hose is blocked.
000002	Diode Temperature Low	Check whether the temperature sensor is loose. Check whether the environment temperature is too low. Turn on the air conditional if the indoor temperature is too low.	
000003	Laser Head Temperature High	Air cooling: Check if the heat sink under the fan of the laser head is blocked and if the fan is working. Check the ventilation status of the laser head.	Water cooling: Check if the chiller is working, check the temperature and pressure is normal (check the water hose is blocked) .
000004	Laser Head Temperature Low	Check whether the temperature sensor connector is loose. Check whether the environment temperature is too low. Turn on the air conditional if the indoor temperature is too low.	
000005	Environment Temperature High	Check the indoor temperature, please turn on the air conditional if it's too high. Check whether the air inlet and outlet of the laser controller are blocked.	
000006	Environment Temperature Low	Check if the temperature sensor plus is loose. Check whether the indoor temperature is too low (15C or below), Turn on the air conditional if it is too low.	
000007	Interlock Open	Check whether the interlock connector is loose. Check whether the connections is shorted	
000009	Crystal 1 Temperature High	Restart the laser by cutting off the power and then turning it on again. Ensure that the ambient temperature is within the operating range.	
000010	Crystal 1 Temperature Low		
000011	Crystal 2 Temperature High		
000012	Crystal 2 Temperature Low		



8.4 Laser common malfunction troubleshooting

Malfunction Description	Solutions
Beam quality degrades	Check whether the laser current value is consistent with the factory report Check whether the external optical components are dirty or damaged, such as the f-theta, beam expander, reflector, and finally the laser window.
No beam output	no indicator light, no strong light : 1. Check whether the laser alarms. 2. Check whether the Diode voltage and current are normal. 3. Check whether the optical fiber is damaged or burned out. With indicator light without no strong light: 1. Check whether the Diode current is normal. 2. Check if the crystal temperature is normal. 3. Check whether the water temperature of the chiller and the Diode temperature is normal.
Power attenuation	1. Check whether the laser current, chiller temperature, PRF and PWF are set correctly. 2. Confirm whether the control signal voltage is normal. 3. Check whether the laser window is broken. 4. Check whether the temperature of the laser is abnormal. If all the above items are correct and the power is still weak, then the crystal temperature needs to be optimized. Crystal optimization method: 1. Switch the laser working mode to 01 internal control mode. 2. Put the power meter in front of the laser window. 3. Click Enable on the Engineer interface of the laser control software. 4. Refer to the power meter, adjust the temperature of crystal 2 first, just click the arrow icon below Crystal 2. If the power rises when the temperature of crystal 2 is increased, continue to increase the temperature, otherwise reduce it until the crystal temperature does not change or decay any more. 3. Adjust the temperature of Crystal 1 with same method and optimize the temperature of Crystal 2 again after completion

Wherever you are, the instant service will be provided for you.

- **ADVANCED OPTOWAVE CORPORATION**

Advanced Optowave Corporation USA
40 Fleetwood Ct, Ronkonkoma, NY 11779, USA
Tel: : 001-631-750-6035
FAX: 001-631-803-4445
Email: info@a-optowave.com
<http://www.a-optowave.com>

- **Shenzhen Inno Laser Technology Co., Ltd.**

11F, A1, 1st phase, Creative City Building, Nanshan District, Shenzhen, China
Tel: +86-755-8635 0999
Fax: +86-755-8635 5000
Floor 6, Building 3, Xinlun Science and Technology Industrial Park,
Zhangwu Crossing, Tangjia Community, Guangming, Shenzhen
Tel: +86-755-2340 5158
Room 16, Floor 5, 99 Commons Building, Pui To Road, Tuen Mun, NT, HK
Email: info@inno-laser.com
<http://www.inno-laser.com>

- **Changzhou Inno Machining Co., Ltd.**

Yingnuo Laser Building, 18-69 Changwu Middle Road,
Wujin District, Changzhou City, Jiangsu Province, China
Tel: +86-519-86339051 / 86339052
Fax: +86-519-86339050
Email: info@inno-laser.com
<http://www.inno-laser.com>